

TABLE OF SHORTCUTS FOR THE NAGRA V

Key combination	Function	Notes
Hold BATT while powering up	Ignore battery selection (forced to OTHER mode)	Typically to use external DC when Lithium is selected
Press SHIFT + Main Selector to STOP	Power OFF when menu is set to MANUAL mode	
SHIFT + BATT	Toggle loudspeaker ON / OFF / AUTO	
SHIFT + AUX IN / LINE OUT pot	Adjust the other pot function	Assuming XX + S is selected in the POT menu
BATT	MONO / STEREO Headphone monitoring	Depending on the Monitor menu selection
Press BATT once	Scroll current main menu settings	
Press BATT twice	Scroll through the TC settings	Assuming TC option is installed
Press SHIFT + STOP / EXE key	Goto Marker	
Press REF. down	Insert Marker	Software version V 4.0 and higher
Press SHIFT + Main Selector to PLAY	Activate internal time code synchronizer	Assuming TC option is installed

MENU Shortcuts

Press EXE from TimeCode menu	Jump to Reset time code menu	Assuming TC option is installed
Press <-- from main Display	Jump to Template and Sc / Tk shortcut menu	