

HD DAC USB driver installation for PC



IMPORTANT : DO NOT CONNECT THE NAGRA HD DAC TO YOUR WINDOWS SYSTEM BEFORE INSTALLING THE DRIVER.

Prerequisites





It is MANDATORY to have your operating system at the latest update level. For Windows XP, you must also install the latest “root certificates” from Microsoft, dated on November 2013; this update is optional, so you must select it manually on the update page.

Step 1 Driver installation


The driver for the USB interface is available on the USB memory stick delivered with your Nagra HD DAC. It will install both the USB and the ASIO driver specific to the Nagra HD DAC. Open the folder holding the driver installation file. Double-click on the file named “**setup_drivers_xp_win7_Win8_32_64.exe**”, and follow the installation process.



Then follow with the ASIO driver installation.



End of installation:




Step 2 Connect your PC to the Nagra HD DAC


Select "No, not this time" at the first prompt for Windows Update connection




Select the automatic software installation at the next prompt



“Amanero Technologies” provided the Nagra HD DAC’s USB software technologies. On PC the Nagra HD DAC is sometimes detected as Amanero Technologies, The PC communicates with the HD DAC USB input so it recognizes him as Amenero, this is normal.



The drivers are installed now, click on “Terminer” means “Completed”.



You should now refer to the playback software settings to make sure you get the best of your Nagra HD DAC.