

ARES-ML SOFTWARE BULLETIN V3.24B0218

Changes from V3.22 to V3.23B0112

- Bugs solved in the German and French language when some sub-menus were selected in the screwdriver menu.
- The pre-record buffer is this time set and frozen to 1 second.

Important:

Our Nagra web site will show 2 different versions depending on the machine serial number.

The first concerns the update for the first 100 machines distributed in 2008 (Serial numbers 7000313025001 up to 7000313025100).

The second concerns the update for the remaining machines with serial numbers starting from 7000313025101 and higher. This is due to a hardware identification difference but is not at all influencing into the quality or possibilities of the machines.

If any mistake was made in the selection for the update, the Ares-ML will display it immediately at the first power on. In this case restart the update with the other ML download.

Changes from V3.22B0305 to V3.24B0218

- Bug solved: Depending on the file settings, the pre-record buffer could overflow.

Luc van Zandycke

(SoftwareBulletinV3.24B0218.doc)

March 27, 2009